



Hold Button Compatibility List

If your phone is not on this list, use the **BA-704**. The **BA-704** works on all phones.

NOTE: The AS-703-M will only work with phones designed to work together.

Phone Maker	Phone Model	Skutch Adapter
AT&T/Lucent	21070	AS-702
AT&T/Lucent	262	AS-702
AT&T/Lucent	272	AS-702
AT&T/Lucent	412	AS-702
AT&T/Lucent	422	AS-702
AT&T/Lucent	4952	AS-702
AT&T/Lucent	612	AS-702
AT&T/Lucent	622	AS-702
AT&T/Lucent	712	AS-702
AT&T/Lucent	722	AS-702
AT&T/Lucent	732	AS-702
AT&T/Lucent	742	AS-702
AT&T/Lucent	752	AS-702
AT&T/Lucent	8102	AS-702
AT&T/Lucent	812	AS-702
AT&T/Lucent	822	AS-702
AT&T/Lucent	830	AS-702
AT&T/Lucent	832	AS-702
AT&T/Lucent	842	AS-702
AT&T/Lucent	843	AS-703-M
AT&T/Lucent	853	AS-703-M
AT&T/Lucent	854	AS-703-M
AT&T/Lucent	874	AS-703-M
AT&T/Lucent	902	AS-702
AT&T/Lucent	912	AS-702
AT&T/Lucent	922	AS-702
AT&T/Lucent	944	AS-703-M
AT&T/Lucent	945	AS-703-M
AT&T/Lucent	952	AS-702
AT&T/Lucent	953	AS-703-M
AT&T/Lucent	954	AS-703-M
AT&T/Lucent	955	AS-703-M
AT&T/Lucent	964	AS-703-M
AT&T/Lucent	974	AS-703-M
AT&T/Lucent	982	AS-702
AT&T/Lucent	983	AS-702
AT&T/Lucent	984	AS-703-M
AT&T/Lucent	992	AS-702-B

Phone Maker	Phone Model	Skutch Adapter
AT&T/Lucent	993	AS-702-B
AT&T/Lucent	1040	CK-1A4
AT&T/Lucent	1070	CK-1A4
AT&T/Lucent	1080	CK-1A4
AT&T/Lucent	90240	AS-703-M
AT&T/Lucent	90529	AS-703-M
AT&T/Lucent	90889	AS-703-M
AT&T/Lucent	E2562	CK-1A2
AT&T/Lucent	E2662	CK-1A2
AT&T/Lucent	EP5962	CK-1A3
AT&T/Lucent	SB67118	CK-1A6
AT&T/Lucent	SIGNATURE	AS-702
AT&T/Lucent	TL76108	CK-1A5
Bell	223	AS-702
Bell	232	AS-702
Bell	259	AS-702
Bell	261	AS-702
Bell	268	AS-702
Bell	367	AS-702
Bell	470	AS-702
Bell	52905	AS-702
Bell	Sonecor 412	AS-703-M
Bell	Sonecor 412CID	AS-703-M
Bell	Sonecor 4900	AS-703-M
Bell	Sonecor BE5200	AS-702 [1]
Bell	Sonecor BE5300	AS-702 [1]
Bell	Techline 420	AS-702 [1]
Casio	SI460	AS-703-SBC
Casio	SA400	AS-703-SBC
Conair	PR3001S	AS-702
Conair	XS1200	AS-702
Cortelco	4125	AS-703-M
Cortelco	412541TP127S	AS-703-M
Cortelco	TP127S	AS-703-M
Cortelco	2740	AS-702-B [2]
Cortelco	2750	AS-703-B [2]
Epic	ET4000	AS-702 -B [1]
Epic	ET4300	AS-702 -B [1]

[1] Requires two AS-702's and a "Y" splitter for the audio


[2] Requires two AS-702-B's and a "Y" splitter for the audio

NEVER ALONE ON HOLD

360-297-8893

hold@drizzle.com

Find your phone and then the adapter that matches. Contact us for options and pricing



ON-HOLD adapters for Digital Announcers for Standalone Phones

Find your phone and then the adapter that will allow you to use

your ON HOLD button to allow callers to hear your customized music and message on hold.

It doesn't matter if you have one line or four, corded or cordless. Advertise your products or services on hold without blowing your budget on expensive upgrades to KEY or PBX phone systems.

Phone Maker	Phone Model	Skutch Adapter
Execufone	ITC-420	AS-703-M
Execufone	420I	AS-703-M
GE	187	AS-702
GE	2-9418	AS-702
GE	2-9420-A	AS-702
GE	2-9435-A	AS-702
GE	2-9435-B	AS-702
GE	2-9435-C	AS-702
GE	2-9436-A	AS-702
GE	2-9438-A	AS-702
GE	2-9480	AS-702
GE	2-9481	AS-702
GE	2-9487	CK-2
GE	2-9488	CK-2
GE	2-9490	AS-702-B
GE	2-9638-A	AS-702
GE	2-9975	AS-702
GE	25403	CK-7
GE	25404	CK-7
GTE	2350	AS-702
IBM	412	AS-703-M
IBM	412CID	AS-703-M
IBM	4900	AS-703-M
Intellitouch	ITC-420	AS-703-M
Intellitouch	420I	AS-703-M
Northern Telecom	Unity	AS-702
Pac Bell	261	AS-702
Pac Bell	FE5350	AS-702
Panasonic	KX-T3110	AS-702
Panasonic	KX-T3120	AS-702
Panasonic	KX-T3122	AS-702
Panasonic	KX-T3135	AS-702
Panasonic	KX-T3145	AS-702
Panasonic	KX-T3155	AS-702
Panasonic	KX-T3160	AS-702 [1]
Panasonic	KX-T3165	AS-702
Panasonic	KX-T3170	AS-702 [1]
Panasonic	KX-T3175	AS-702
Panasonic	KX-T3280	AS-702
Panasonic	KX-T3281	AS-702
Panasonic	KX-T3980-H	AS-702

Phone Maker	Phone Model	Skutch Adapter
Panasonic	KX-T3980-R7	AS-702
Panasonic	KX-T3981	AS-702
Panasonic	KX-TC930	AS-702
Panasonic	KX-TG2000	CK-1P7
Panasonic	KX-TG2720	CK-1P2
Panasonic	KX-TG2740	CK-1P2
Panasonic	KX-TG4000	CK-1P7
Panasonic	KX-TG4500	CK-1P7
Panasonic	KX-TG5480	CK-1P3
Panasonic	KX-TG6500	CK-1P3
Panasonic	KX-TG6502	CK-1P3
Panasonic	KX-TG6700	CK-1P4
Panasonic	KX-TG6702	CK-1P4
Panasonic	KX-TG650	CK-1P3
Panasonic	KX-TG9381T	CK-1P6
Panasonic	KX-TG9382T	CK-1P6
Panasonic	KX-TG9391T	CK-1P6
Panasonic	KX-TG9392T	CK-1P6
Panasonic	KX-TGA200	CK-1P7
Panasonic	KX-TGA400	CK-1P7
Panasonic	KX-TGA420	CK-1P7
Panasonic	KX-TGA650	CK-1P3
Panasonic	KX-TGA670	CK-1P4
Panasonic	KX-TS20	AS-702
Panasonic	KX-TS21	AS-702
Panasonic	KX-TS25	AS-702
Panasonic	KX-TS27	AS-702
Panasonic	KX-TS208	AS-702
Panasonic	KX-TS3282	AS-702-B
Panasonic	KX-TS4100	CK-1P5
Panasonic	KX-TS4200	CK-1P5
Panasonic	KX-TS4300	CK-1P5
Panasonic	KX-TSC14	AS-702-B
Panasonic	VA-8400	AS-702
Panasonic	PQLV30024ZB	CK-1P3
Phone Mate	PMG-4125	AS-703-M
Qwest	NSQ412	AS-703-H
Radio Shack	1752	AS-703-M
Radio Shack	206 – old	AS-702
Radio Shack	208 – old	AS-702
Radio Shack	209 – old	AS-702

[1] Requires two AS-702's and a "Y" splitter for the audio

[2] Requires two AS-702-B's and a "Y" splitter for the audio

Hold Button Compatibility List

Phone Maker	Phone Model	Skutch Adapter
Radio Shack	210 / 43-623	AS-702
Radio Shack	212 / 43-463	AS-703-M
Radio Shack	612 / 43-461	AS-703-M
Radio Shack	43-373D	AS-702
Radio Shack	ET-1753/43-1753	AS-702
Radio Shack	43-430	AS-702
Radio Shack	ET-146 / 43-642	AS-702
Radio Shack	ET-180	AS-702
Radio Shack	ET-181 / 43-470	AS-702
Radio Shack	ET-184	AS-702
Radio Shack	ET-192	AS-702
Radio Shack	ET-193	AS-702
Radio Shack	ET-293 / 43-622	AS-702
Radio Shack	ET-469 / 43-469	AS-702
RCA	25201	AS-702-B
RCA	25210	CK-1R2
RCA	25250	CK-1R2
RCA	25255	CK-1R3
RCA	25403	CK-7
RCA	25404	CK-7
RCA	25413	CK-7
RCA	25414	CK-7
RCA	25415	CK-7
RCA	25423	CK-7
RCA	25424	CK-7
RCA	25425	CK-7
SBC	2105	AS-702
SBC	4000	AS-702 [1]
SBC	410	AS-703-SBC
SBC	420	AS-703-M
Skutch	HT-878	AS-702
Smarttalk	208VX	AS-702
Sony	IT-M804	AS-702-B [2]
South Western Bell	FT325	AS-702
South Western Bell	FT360	AS-702
South Western Bell	FT365BL	AS-702
South Western Bell	FT412	AS-702 [1]
Spectra Phone	FP-40M	AS-702

Phone Maker	Phone Model	Skutch Adapter
Starplus II	HAC2605	AS-702
Starplus II	HAC2606	AS-702
TDS	TDS-412	AS-703-H
TMC	ET4000	AS-702 -B [1]
TMC	ET4300	AS-702 -B [1]
TT Systems	412	AS-703-M
TT Systems	412CID	AS-703-M
TT Systems	4300	AS-702 [1]
TT Systems	4900	AS-703-M
TT Systems	5200	AS-702 [1]
TT Systems	5300	AS-702 [1]
TT Systems	7993	AS-702 [1]
Uniden	UB-420	AS-703-M
Uniden	420	AS-703-M
Verizon	NSQ412	AS-703-H

[1] Requires two AS-702's and a "Y" splitter for the audio

[2] Requires two AS-702-B's and a "Y" splitter for the audio